



# ***Pullman Ermator***

## Air evacuation hole pump

Changing procedure for increased function when using both extraction and evacuation.



### 1. Find where the hole will be

Draw a vertical line on the pump from the center of the inlet.



### 2. Height marking on pump

To get the best result with the air evacuation hole you need to drill the hole 76-80mm from the bottom .



### 3. Drilling pump

When the hole is marked, just drill the new air evacuation hole with a 8,0mm drill.



### 4. Result

When the new hole is finished, remount the pump in the tank and start using the machine .

**Pullman-Ermator AB**  
Industrivägen 10  
777 34 Smedjebacken  
Tel: +46 (0)240 66 09 60  
Fax: +46 (0)240 66 30 60  
Email: [info@pullman-ermator.se](mailto:info@pullman-ermator.se)

