

# Pullman Ermator Service Sheet

## Filter cleaning S-line



Create a vacuum with the inlet seal.



Push down the cleaning valve lever. Repeat 5 times.



Turn off the machine and let the dust fall into the bag.

## Control before use



Check for any dirt which has stuck in the flap and remove the dirt.



Pull out the bag so it does not get stuck in the flap.



Push up the flap and start the machine.



## Longopac



Pull the bag down.



Attach two stripes with a 10cm gap.



Cut between the stripes.

## Changing Longopac



Pick up a Longopac and put it with the bag's inner end upwards and the outer end facing downward.



Mount the bag into the holder and snip off the ties.



Remount the complete Longopac, tighten internal clearance with a strap, the outer clearance using stripes.

[www.pullman-ermator.se](http://www.pullman-ermator.se)

Tel. 0240-660960

## Replace coarse filter S-line



Loose the three clamps.



Pull a plastic bag outside of the filter and down over the tank.



Lift the filter and seal the bag. Remount the new filter and refit the top cover.

## Replace HEPA-filter S-Line



Loosen the knurled thumb nuts to the filter cap.



Lift gently the HEPA - filter and place it in a bag and seal immediately.



Insert a new HEPA-filter and place it carefully in the center, tighten the knurled thumb nuts but not too hard, it may damage the filter.

